

Waterborne Woodsman Penetrating Oil Stain

Surface Preparation

Existing Stains

Remove all the weakly adhering coating by sanding. Treat with Resene Moss & Mould Killer (Data Sheet D80).

Exposed Timber (greater than 1 week)

Remove any gross contamination and semi-detached cellulose fibres. Treat with Resene Moss & Mould Killer (Data Sheet D80).

New Timber

Ensure surface is dry and free from dirt, dust and loose material.

Caution:

Sanding dusts from some hardwoods are considered carcinogenic, and all old timber sanding dusts should be considered potentially harmful. Always wear an efficient dust mask.

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply by brush, roller or spray. Saturate surface with Resene Waterborne Woodsman. During application stir the contents of the can frequently to ensure even distribution of colour. Aim to achieve the targeted coverage for the substrate as outlined below.

Typical Coverage

Badly Weathered Timber

1st coat 3-4 square metres per litre
2nd coat 5-7 square metres per litre

Dressed Timber

1st coat 10-12 square metres per litre
2nd coat 12-14 square metres per litre
Apply a 3rd coat 12-14 square metres per litre after about 3-6 months.

Rough Sawn Timber

1st coat 4-6 square metres per litre
2nd coat 9-11 square metres per litre

Precautions

1. Contains powerful fungicides. Avoid skin contact. If any skin contact occurs, wash skin thoroughly with soap and water immediately. Do not scrub the skin.
2. Avoid breathing vapour - use with adequate ventilation.

Information contained in this Data Sheet is re-validated every two years following issue date.

Please ensure current Data Sheet is consulted prior to specification or application of Resene products.

If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

Resene

the paint the professionals use

In New Zealand, PO Box 38242, Wellington Mail Centre,
call 0800 RESENE, visit www.resene.co.nz or email advice@resene.co.nz

In Australia, PO Box 785, Ashmore City, Queensland,
call 1800 738 383, visit www.resene.com.au or email advice@resene.com.au