

# Paint Effects

## Brushed Metallic

Resene Enamacryl Metallic may be used in a variety of ways as far as paint effects go and is available in a wide colour range. Each Resene Enamacryl Metallic has a matching tinted basecoat. Besides walls, Resene Enamacryl Metallic may be applied to items of furniture, accessories, mirror and picture frames. These items are best finished in a final coat of Resene Aquaclear gloss for durability and cleanability.



### You will need:

- 120-125mm synthetic filament brush
- Resene Enamacryl Metallic tinted to Resene Axis
- Resene Lumbersider tinted to Resene Nullarbor
- Resene No.1 roller
- Roller tray
- Small synthetic filament brush for cutting in

### Tips:

Before you start your project try out different combinations and practice your application method on a piece of card until you are happy with the result.

See the Resene Metallics and Special Effects colour chart for a full range of colours.

See the Resene Paint Effects brochure for a range of paint effects samples or visit the Resene website for more Paint Effects ideas - [www.resene.co.nz/homeown/use\\_colr/paint\\_effects.htm](http://www.resene.co.nz/homeown/use_colr/paint_effects.htm) (NZ) or [www.resene.com.au/homeown/use\\_colr/paint\\_effects.htm](http://www.resene.com.au/homeown/use_colr/paint_effects.htm) (AUST).

Resene Paint Effects brochures and Resene Metallics and Special Effects colour charts are available free from Resene ColorShops or order your copy online from [www.resene.co.nz/comn/whtsnew/colrdr/order.htm](http://www.resene.co.nz/comn/whtsnew/colrdr/order.htm) (NZ) or [www.resene.com.au/comn/whtsnew/colrdr/order.htm](http://www.resene.com.au/comn/whtsnew/colrdr/order.htm) (AUST).

### Method:

- Using Resene Nullarbor cut in around the edges of the wall with the small brush and apply one good coat with the roller.



- Apply a coat of Resene Axis using the same method as above. Take the roller as close as you can to the edge of the wall then finish by laying off in one direction.



- The final topcoat may be done two ways. Apply directly with the larger brush in a criss-cross manner or use the roller to apply an area of paint about a metre square and use a dry brush to create the criss-cross effect. Do some test boards first and use whichever technique you find easiest. Make sure you use the same method for any other areas so that the finish looks consistent.



**In New Zealand:**  
32-50 Vogel Street, Lower Hutt,  
PO Box 38-242, Wellington Mail Centre  
Call 0800 RESENE, visit [www.resene.co.nz](http://www.resene.co.nz)  
or email us at [advice@resene.co.nz](mailto:advice@resene.co.nz)

**In Australia:**  
PO Box 785, Ashmore City, Queensland 4214  
Call 1800 738 383, visit [www.resene.com.au](http://www.resene.com.au)  
or email us at [advice@resene.com.au](mailto:advice@resene.com.au)

Project by Janet Scard  
Photography by Joseph Zou

# Resene

the paint the professionals use