

















Step 1

Measure up your frame timbers and cut to size.

# Step 2

Draw out your circles on the exterior plywood using a template like a bowl or plate. Cut circles with the jigsaw and sand the edges.

# Step 3

Assemble the T-Brace. Measure out for the screws in the centre, pre-drill and screw together.

# Step 4

Measure out for the screws for installing each tier, 200mm up from the bottom of each tier post.

### Step 5

Pre-drill and screw together. I used a clamp to hold the timbers in place.

## Step 6

Apply Resene exterior finish. I used Resene Furniture & Decking Oil Exterior to show off the timber.

#### Step 7

Using brush or roller apply paint each side of plant stand circles. I have used Resene Walk-On Flooring & Paving paint for durability.

# Step 8

Measure to the centre of each circle and pre-drill. Attach the circles to the centre of the top of each tier post. ■



Jane Horne and partner Simon Bartholomew design and develop projects from their studio (plainandsimple.co.nz) in Christchurch, managing projects throughout the South Island.