

Resene SpaceCote Clear

waterborne low
sheen

Resene SpaceCote Clear is a low sheen clear finish, designed to bring enamel style toughness to broadwall areas, allowing you to get a low sheen finish without sacrificing durability. Ideal to protect interior wall paints and Mason wallpaper. A durable low odour finish with scuff, scrub and burnish resistance.

interior

Typical uses

- Painted surfaces
- Mason wallpaper

Vehicle type	Acrylic
Pigmentation	None
Solvent	Water
Finish	Low sheen
Colour	Milky – dries clear
Dry time (minimum)	Touch dry 45 minutes
Recoat time (minimum)	2 hours
Theoretical coverage	11 sq. metres per litre per coat
Usual no. of coats	2
Abrasion resistance	Very good
Chemical resistance	Good
Heat resistance	Good
Solvent resistance	Good
Durability	Excellent
Thinning	In hot dry conditions may be thinned with up to 5% Resene Hot Weather Additive to slow drying
Clean up	Water
VOC	27 grams per litre (see Resene VOC Summary)

Physical properties

Vehicle type	Acrylic
Pigmentation	None
Solvent	Water
Finish	Low sheen
Colour	Milky – dries clear
Dry time (minimum)	Touch dry 45 minutes
Recoat time (minimum)	2 hours
Theoretical coverage	11 sq. metres per litre per coat
Usual no. of coats	2
Abrasion resistance	Very good
Chemical resistance	Good
Heat resistance	Good
Solvent resistance	Good
Durability	Excellent
Thinning	In hot dry conditions may be thinned with up to 5% Resene Hot Weather Additive to slow drying
Clean up	Water
VOC	27 grams per litre (see Resene VOC Summary)

Performance

Performance and limitations

1. Very durable, abrasion resistant finish that may be easily cleaned. Ideal for GIB® ToughZone® areas.
2. Reduced side sheen minimises the appearance of minor surface defects.
3. Non-yellowing.
4. Resene SpaceCote Clear may also be used over Resene FX Metallic decorative paint finishes. Always check a sample panel to confirm the surface finish before completing the full project.

Limitations

1. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
2. Although serviceable within 12-48 hours, full print and solvent resistance takes 30 days to develop.
3. Not recommended for use as a varnish on large areas of interior timber.
4. Will not penetrate or reinforce weak surfaces.

SpaceCote Clear waterborne low sheen

Surface preparation

Ensure substrates to be coated are in sound condition, dry, free from dirt, dust, loose material, curing and release membranes, oil and salt.

If moss and mould are present, treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)).

Ensure wallpaper is clean and free from any powdery materials.

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Do not shake contents, rather stir well with a wide flat stirrer.

Apply by brush, roller (Resene No.4 roller sleeve) or spray. Apply two coats of Resene SpaceCote Clear allowing at least two hours between coats.

Do not brush or roll excessively to avoid excess foaming of the material. Lay-off with care.

Wallpaper – first test on a small area to ensure that the finished appearance is as desired and that there is no reaction with wallpaper inks. While it can be used on other wallpapers, the plasticiser in some vinyl wallpapers can make topcoats feel sticky to touch. Always trial in an inconspicuous area first and leave for two weeks before coating all wallpaper.

Precautions

1. Do not apply in direct hot sunlight.

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 924, Beenleigh, Qld 4207
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle.