

# Painting timber, weatherboards and linea in good condition

Treat moss and mould with  
Resene Moss & Mould Killer  
(D80)

Wash and scrub using  
Resene Paint Prep and  
Housewash (D812)

Sand any flaking paint using  
120-150 grit zinc sterate  
sandpaper

Spot prime using Resene  
Quick Dry primer (D45)

Fill any holes and gaps,  
lightly sand filled areas  
with 220 grit sandpaper  
and reprime with Resene  
Quick Dry primer (D45)

2 coats of Resene  
Sonyx 101 semi-gloss (D30)  
or Resene Lumbersider  
low sheen (D34)

2 coats of  
Resene Decorator  
Acrylic Gloss (T3)



Resene. Licensed  
products since 1996

## Notes:

- Resene Sonyx 101 is our recommended topcoat for Linea. As there are often imperfections in the boards that Resene Hi-Glo will highlight. Resene Lumbersider is an option especially if the boards are in poor condition with lots of filled nailheads, joins etc or if a more rustic look is preferred.
- Linea weatherboards utilise innovative ceramic technology to produce a very durable, movement and moisture resistant substrate – and is an ideal substrate for painting as it overcomes many of the movement related issues inherent in timber.
- Its lack of movement and inertness mean that strong colours can be used without the risk of warping and shrinkage – problems common to timber weatherboards. As a result it is proving popular with designers and architects wishing to use stronger colours on their designs.
- While they arrive at a building site primed they will need spot priming for any nail holes, cut edges and any sanded areas.
- For maximum durability we recommend three topcoats are applied - this increases the coverage and therefore durability over sharper edged profiles.
- To extend colour durability still further a coat of Resene Multishield+ (flat, satin or gloss) can be applied (usually over Resene Lumbersider).
- Repainting older fibre cement weatherboards such as Hardiplank and Weathersider is usually straightforward. Our recommended topcoat is Resene Lumbersider. For preparation information and what to do if they contain asbestos refer to your Resene ColorShop.

### Key accessories essential to complete the job

- Resene Paint Prep and Housewash
- A good quality brush is recommended
  - 75-83mm Legend brush for men
  - 63-75mm Legend brush for women
- Contract filler for any cracks or nailheads
- Exterior No More Gaps
- 220 or 180 grit zinc stearate sandpaper for sanding fillers etc.
- Paint pot to decant into if using 10 litre pails

### Add ons – to make the job easier or quicker

- Drop sheets
- Resene Hot Weather Additive for hot dry conditions
- Painter dusting brush
- Sanding blocks
- Painter gloves (good for sanding and painting)
- Resene MoulDefender