





Painting timber and weatherboards in good condition

Treat moss and mould with Resene Moss & Mould Killer

Wash and scrub using Resene Paint Prep and Housewash

Sand any flaking paint using 120-150 grit zinc sterate sandpaper

Spot prime using Resene Quick Dry Primer

Fill any holes and gaps, lightly sand filled areas with 220 grit sandpaper and reprime with Resene Quick Dry Primer

For a semi gloss finish recommend 2 coats of Resene Sonyx 101 waterborne semi-gloss

For a high gloss finish recommend 2 coats of Resene Hi-Glo waterborne gloss

Also consider using





2. Painting timber and weatherboards in good condition

Notes:

- Resene Hi-Glo, Resene Sonyx 101 and Resene Lumbersider are formulated using costly
 adhesion promoters so they will adhere exceptionally well to aged paints, including old
 enamels without the need for extensive sanding of otherwise sound paints.
 - As an indication of their adhesion properties Resene Hi-Glo and Resene Sonyx 101 can be applied directly to weathered COLORSTEEL® (or COLORBOND®).
- However any loosely bound contaminants or mould on the paint surface must be removed before painting or the paint will not bond to the old surface.
 - As exterior paint ages it will succumb to constant U.V. attack and will slowly deteriorate, with the top layer breaking down and 'chalking'. The 'chalk' is mostly loosely bound pigments of TiO₂ (Titanium Dioxide) for white paint.
- 'Chalk' and other contaminants need to be removed (dechalking) and the most effective way is to use Resene Paint Prep and Housewash and wash and scrub the same way you would a car scrubbing flaking areas and washing paintwork in sound condition. It is also very effective at loosening and removing salt.



- Any flaking paint should be scrubbed to remove the worst affected areas (a short bristled brush or Scotchbrite pad is ideal) and sanded using 120 to 150 grit zinc sterate sandpaper ensuring the edges are feathered before spot priming using Resene Quick Dry Primer.
- After sanding, prime the same day as night time dew will creep under the freshly sanded paintwork and the edges will curl and lift – plan the prep work so that this is achieved.

Key accessories

- Resene Moss & Mould Killer
- Resene Paint Prep and Housewash
- A good quality brush is recommended
 - 75-83mm Legend brush for men
 - 63-75mm Legend brush for women
- Contract filler for any cracks or nail holes
- 100 to 120 grit zinc sterate sandpapers for preparing and 180grit for sanding fillers etc.
- Paint pot to decant into if using 10 litre pails

Add ons

- Drop sheets
- Resene Resene Hot Weather Additive for hot dry conditions
- Painter dusting brush
- Sanding blocks
- Painter's gloves (good for sanding and painting)
- Resene MoulDefender