Resene

• 190mm x 20mm timber cut

to the following lengths:

– 2 x 210mm (side

- 2 x 500mm (back)

timber (top edge)

Toy chair

• PVA glue

Sandpaper

• Screwdriver

• Tape measure

• Saw

• Resene EzyFill Quick

to Resene Gorse

Resene Quick Dry

Resene Lustacryl tinted

You will need:

supports)

- 380mm (seat)

 $\star \star \star$ Difficulty level \star easy $\star \star$ moderate $\star \star \star$ challenging

•

• 50mm panel pins

Drill with 3mm drill bit

• Putty knife or similar

65mm screws

Clean cloth

• Large clamp

Nail punch

• Paintbrush

• Hammer

Toys and Games with Mark Rayner - 35

It's easy to create this vibrant chair for toys and dolls with a little bit of help from Resene.



To get the look: Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Fringy Flower.



Other ideas: For a bright orange effect paint the chair with Resene Lustacryl tinted to Resene Hi Jinx.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.

- 20mm x 20mm x 380mm • Pencil



Step one Measure, mark and cut the timber to the dimensions listed above.



Step two Clamp one of the side supports to the underside edge of the seat, as shown and fix with PVA glue and 65mm screws. Drill pilot holes first and countersink the screw heads. Repeat

with the second side

support.



Step three Attach the back into position, as shown. Again, fix with PVA glue and 65mm screws, drilling pilot holes first and countersinking the screw heads.



Step four

Attach the top edge along the top of the back, as shown, fixing with PVA glue and 50mm panel pins. Punch the nail heads into the wood with a nail punch.



Step five Fill the screw and nail heads with Resene EzyFill Quick and allow to dry.



Step six Sand the entire chair and wipe off any sanding residue with a clean cloth.



Step seven Apply one coat of Resene Quick Dry to the chair and allow to dry.



Step eight Apply two coats of Resene Lustacryl tinted to Resene Gorse to the chair, allowing two hours for each coat to dry.

In Australia: Call 1800 738 383, visit www.resene.com.au or email advice@resene.com.au



In New Zealand: Call 0800 RESENE (737 363), visit www.resene.co.nz or email advice@resene.co.nz