Resene

Splatter chair

Difficulty level ★easy ★★moderate ★★★challenging

Fun with Furniture with Mark Rayner - 3

You will need:

- Clean cloth
- Old painted or varnished wooden chair
- Paintbrushes (including a medium artists' brush)
- Resene Aquaclear satin
- Resene Lumbersider tinted to Resene Nite Life
- Resene testpots in the following colours:
- Resene Bowie, Resene Desire and Resene Outrageous
- Resene Waterborne Smooth Surface Sealer
- Sandpaper



Step one

Remove the upholstered seat and lightly sand the chair frame to provide a 'key'. Wipe off any sanding dust with a clean cloth.



Step two

Apply one coat of Resene Waterborne Smooth Surface sealer to the chair frame and allow to dry for two hours.



Step three

Paint the chair frame with two coats of Resene Nite Life, allowing two hours for each coat to dry.



Step four

Using an artists' brush, dribble and splatter Resene Desire over the chair frame, as shown.



Step five

Repeat step four using Resene Outrageous.



Step six

Repeat step four using Resene Bowie. Allow to dry thoroughly (a minimum of two hours).



Step seven

Apply two coats of Resene Aquaclear, allowing two hours for each coat to dry.



Step eight

Replace the upholstered seat.

Transform an old chair into a work of modern art with the help of a few Resene testpots.



To get the look:

Mark painted the background wall with Resene SpaceCote Low Sheen tinted to Resene Knock Out.



Other ideas:

Create a cool blue combination using Resene Anchor, Resene Aquarius and Resene Elvis over a basecoat of Resene True Blue.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm

www.resene.com.au/ artists/artists_canvas.htm.

