Resene

Display case

* The second sec

You will need:

- Clean cloth
- Hammer
- Old wooden corner unit
- Paintbrush
- Pliers
- Resene Enamel Undercoat
- Resene Mineral Turpentine
- Resene Paint Pot
- Resene Super Gloss enamel tinted to Resene Double Alabaster
- Sandpaper



Step one Remove the back panels of the unit, taking care not to damage the wooden frame.



Step two Remove any old nails with pliers.



Step three Sand the unit with a medium grade sandpaper, followed by a fine grade sandpaper.



Step four Wipe off any sanding residue with a clean cloth.

Transform an old corner unit into a chic display case with a little bit of help from Resene.



To get the look: Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Quarter Cararra.





Step five Apply one coat of Resene Enamel Undercoat to all surfaces of the unit. Allow to dry for 12 hours.



Step six Wash brush using Resene Mineral Turpentine.



Step seven Apply one coat of Resene Double Alabaster to all surfaces of the unit and allow paint to dry for 16 hours. Wash brush using Resene Mineral Turpentine.



Step eight

Apply a second coat of Resene Double Alabaster to all surfaces of the unit and allow paint to dry for 16 hours. Wash brush using Resene Mineral Turpentine. Other ideas: For a rich glossy black finish use Resene Super Gloss tinted to Resene Black.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.

In Australia: Call 1800 738 383, visit www.resene.com.au or email advice@resene.com.au



In New Zealand: Call 0800 RESENE (737 363), visit www.resene.co.nz or email advice@resene.co.nz