Resence Distressed kitchen cupboard



→ Difficulty level ★easy ★★moderate ★★★challenging

Fun with furniture with Mark Rayner - 34

You will need:

- **Bucket with warm water**
- **Clean cloths**
- Old kitchen cupboard
- **Paintbrushes**
- Resene Interior Paintwork Cleaner
- Brass cupboard door handles
 Resene Lustacryl tinted to
 Resene testpots of Resene Double Pearl Lusta
 - Resene SpaceCote Low Sheen Kitchen & Bathroom tinted to Resene Alabaster
- Resene Dingley (x2)
- Resene Waterborne **Smooth Surface Sealer**
- Sandpaper
- Screwdriver



Step one

Remove existing door handles and wash the cupboard thoroughly with Resene Interior Paintwork Cleaner. Wipe clean and allow to dry.



Step two

Lightly sand the entire cupboard to 'key' the surface and wipe off any sanding residue with a clean cloth.



Step three

Apply one coat of Waterborne Resene Smooth Surface Sealer to the cupboard and allow to dry.



Step four

Apply two coats of Pearl Resene Double Lusta to the inside of the cupboard and allow two hours for each coat to dry.



Step 5

Paint the outside of the cupboard with one coat of Resene Dingley and allow two hours to dry.



Step six

Apply two coats of Resene Alabaster to the outside of the cupboard and allow two hours for each coat to dry.



Step seven

Lightly sand the edges and corners of the cupboard to allow some of the darker colour to show through.



Step eight

Fix the brass handles into place.





To get the look:

Mark also painted the surrounding wall with Resene SpaceCote Low Sheen Kitchen & Bathroom tinted to Resene Alabaster.



Other ideas:

For a bolder distressed look apply one coat of **Resene Crackle effect** over a two coat base of Resene Pohutukawa with one topcoat of Resene Rich Cream.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.



