

# **Plant support**



**★★** Difficulty level ★easy ★★moderate ★★★challenging

Ways with wood with Mark Rayner – 33

## You will need:

- 20mm x 20mm timber garden stakes
- 40mm x 2mm galvanised jolt head nails
- Hammer

Paintbrush

A STATE OF THE STA

- Pencil
- PVA glue (exterior)

The state of the s

- Resene Waterborne
   Woodsman penetrating
   oil stain tinted to Resene
   Fern Frond
- Sandpaper
- Saw
- Set square
- Tape measure



### Step one

Measure nine 600mm lengths and five 1200mm lengths from the 20mm x 20mm garden stakes.



Step two

Mark a ninety degree saw line across the garden stakes, as shown, using the back of the saw as a guide.



Step three

Cut the garden stakes using the pencil marks as a guide.



Step four

Smooth any rough edges with sandpaper, as shown.



Step five

Stain the garden stakes with one coat of Resene Fern Frond and allow to dry for 24 hours. Apply a second coat and allow to dry.



Step six

Attach two of the 600mm lengths to two of the 1200mm lengths to form a rectangle, fixing with 40mm nails and PVA glue. Use the set square to ensure the corners are at right angles.



Step seven

Fix the centre horizontal cross piece, as shown, using PVA glue and nails.



#### Step eight

Fix the remaining horizontal cross pieces, ensuring that they are equally spaced and fix the vertical pieces in the same way. Allow the glue to dry.



Create this stylish plant support using a few garden stakes and Resene Waterborne Woodsman penetrating oil stain.



## To get the look:

Mark painted the background garden wall with Resene Lumbersider tinted to Resene Amulet.



#### Other ideas:

For a contrasting effect try Resene Waterborne Woodsman tinted to Resene Pitch Black against a background of Resene Alabaster.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.



