

Inject a splash of bright red into the garden with this colourful planter box.

### You will need:

- 1.8m fence palings (x3)
- 100mm x 50mm timber (approx 440mm)
- 50mm exterior wood screws
- Paintbrush
- Pencil
- Resene Lumbersider tinted to Resene Poppy
- Resene Quick Dry
- Sandpaper
- Saw
- Screwdriver
- Tape measure



**Step one**  
Measure and mark four 550mm lengths and four 600mm lengths from the fence palings.



**Step two**  
Cut these lengths to size.



**Step three**  
Smooth any rough edges with sandpaper.



**Step four**  
Assemble the pieces to form two square frames, as shown. Fix at each corner with 50mm screws.



**Step five**  
Measure, mark and cut four 110mm pieces from the 100mm x 50mm timber. Smooth any rough edges with sandpaper.



**Step six**  
Attach the two frames together by screwing the four blocks of timber at each inner corner of the planter box, as shown.



**Step seven**  
Apply one coat of Resene Quick Dry to the planter box and allow to dry.



**Step eight**  
Apply two coats of Resene Lumbersider tinted to Resene Poppy to the planter box, allowing two hours for each coat to dry.



**To get the look:**  
Mark painted the terracotta pot with Resene Malibu.



**Other ideas:**  
This planter box could also be stained with any colour from the Resene Waterborne Woodsman range.

For more ideas and inspiration visit your local Resene ColorShop or [www.resene.com/colorshops](http://www.resene.com/colorshops).

Check out more project ideas online [www.resene.com/projects](http://www.resene.com/projects).