Resene

Concrete pad



Difficulty level ★easy ★★moderate ★★★challenging

Weekend DIY with Mark Rayner - 70

You will need:

- Bucket with clean water
- Concrete pad or patio
- Garden hose with clean running water
- Large paintbrush
- Mineral turps
- Paint stirrer

- Resene Moss & Mould Killer
- Resene paint pot
- Resene Sureseal

ALL CLASSES CONTRACTOR SERVICES

- Resene Walk-on flooring and paving paint tinted to Resene Fahrenheit
- Rubber gloves
- Stiff bristled brush



Step 1 Mix one part Resene Moss & Mould Killer to five parts clean water.



Step 2Brush onto the concrete and leave for 24 hours.



Step 3
Rinse the concrete thoroughly with clean water and allow to dry.



Step 4Carefully stir the Resene Sureseal.



Step 5Apply one coat of Resene Sureseal to the concrete and allow to dry.



Step 6 Clean brush in mineral turps.



Step 7
Carefully stir the Resene
Walk-on flooring and
paving paint tinted to
Resene Fahrenheit.



Step 8
Apply two coats of Resene Walk-on flooring and paving paint tinted to Resene Fahrenheit to the concrete allowing two hours for each coat to dry.





To get the look:
Mark painted the
background shed door
with Resene Lustacryl
tinted to Resene
Catalyst.



Other ideas:
For a soft green look
paint the concrete
with Resene Walk-on
flooring and paving
paint tinted to Resene
Coriander.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.



