

You will need:

- 25cm 'Long Tom' terracotta pots (x4)
- 21cm terracotta pots (x2)
- Paint stirrers
- Paintbrushes
- Pencil
- Resene Aquapel & Terracotta Sealer
- Resene Lumbersider tinted to Resene Breeze
- Resene Woodsman tinted to Resene Totem Pole
- Sandpaper
- Saw
- Tape measure
- Tongue-and-groove landscaping timber (approx 2.25m)



Step 1
Measure, mark and cut the landscaping timber into three 750mm lengths and then smooth any rough edges with sandpaper.



Step 2
Carefully stir the Resene Woodsman tinted to Resene Totem Pole.



Step 3
Apply one coat of Resene Woodsman tinted to Resene Totem Pole to the pieces of landscaping timber and allow to dry.



Step 4
Apply a second coat of Resene Woodsman tinted to Resene Totem Pole to the pieces of landscaping timber and allow to dry.



Step 5
Seal the inside and outside of each terracotta pot using Resene Aquapel & Terracotta Sealer. Allow to dry.



Step 6
Carefully stir the Resene Lumbersider tinted to Resene Breeze.



Step 7
Apply one coat of Resene Lumbersider tinted to Resene Breeze to the terracotta pots and allow to dry.



Step 8
Apply a second coat of Resene Lumbersider tinted to Resene Breeze to the terracotta pots. Once dry, place the lengths of timber onto the terracotta pots in tiers to form the shelving.

It's easy to create some simple shelving for a glasshouse or conservatory with a little bit of help from Resene.



To get the look: Mark painted the glasshouse woodwork with Resene Lustacryl tinted to Resene Quarter Alabaster.



Other ideas:
For a relaxed blue effect use a combination of Resene Woodsman tinted to Resene Pickled Bluewood and Resene Lumbersider tinted to Resene Quarter Dusted Blue.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/colorshops.

Check out more project ideas online www.resene.com/projects.