

Get busy to turn the tables

Mark Rayner transforms a kitset table ideal for backyard or beach gardens (it's very wind resistant) using Resene Timber and Furniture Gel.

You will need:


- Kitset barbecue table (including bolts and screws needed for assembly)
- Resene Timber and Furniture Gel in Resene Silvered Grey
- Screwdriver
- Adjustable spanner
- Small paintbrush
- Clean lint-free cloth
- Latex gloves
- Sandpaper

Top tip:

If you're using this product on an old, weathered table, the wood should first be treated with Resene Moss & Mould Killer and then cleaned with Resene Timber and Deck Wash.




For more on paints
phone 0800 RESENE
or visit www.resene.co.nz




1

Following manufacturer's instructions, place the tabletop face down on flat ground and fix the leg sections into position, bolting through the underside brackets, as shown.




2

Fix the diagonal support braces to the legs, screwing into position through the pilot holes provided.




3

Turn the table the right way up and screw through the pilot holes in the table top, fixing the support braces to the underside of the table top.




4

Position seats on to seat supports and fasten with screws.



5

Lightly smooth off any rough edges with sandpaper.



6

Using a small paintbrush, carefully apply the Resene Timber and Furniture Gel between the slats on the table top and seats.



7

Turn table upside down. Apply the Resene Timber and Furniture Gel to the underside of its top and seats with a clean lint-free cloth. Lightly rub the gel along the timber grain using medium pressure to help penetration.



8

Turn the table the right way up and apply the Resene Timber and Furniture Gel to the rest of it. Leave to dry for an hour. Apply a second coat of gel to the entire table. Allow this to dry well before using the table.