Resene

Storage box



→ Difficulty level ★easy ★★moderate ★★★challenging

Weekend DIY with Mark Rayner - 6

You will need:

- 16mm MDF cut to the following dimensions:
 2 x 400mm x 400mm
 2 x 400mm x 366mm
 1 x 366mm x 366mm
- 40mm screws
- Clean cloth

- Drill
- Low tack masking tape
- Paintbrush
- Pencil
- PVA glue
- Resene Enamacryl gloss waterborne enamel tinted to Resene Reservoir
- Resene SpaceCote Flat tinted to Resene Billabong
- Resene Quick Dry
- Resene testpot roller and tray
- Ruler
- Sandpaper
- Saw
- Screwdriver



Step one

Measure, mark and cut the MDF to the dimensions listed above.



Step two

Smooth any rough edges with sandpaper.



Step three

Attach the MDF pieces together to form a box, fixing at each edge with PVA glue and screws (drill pilot holes first).



Step four

Wipe off any excess glue with a clean cloth and allow glue to dry. Lightly sand the box.



Step five

Apply one coat of Resene Quick Dry to the box and allow two hours to dry.



Step six

Apply two coats of Resene Reservoir to the box, allowing two hours for each coat to dry.



Step seven

Mask off an angled rectangle, as shown, using low tack masking tape.



Step eight

Apply two coats of Resene Billabong to the masked area. Allow two hours for the first coat to dry and then apply a second coat, carefully peeling off the masking tape before this coat dries. Allow to dry for two hours.



Create this handy

with instant chalkboard label using a selection of cool

box

MDF storage

Resene colours.

Top tip:

Mark painted the background wall with Resene SpaceCote Low Sheen tinted to Resene Nirvana and the skirting board with Resene Enamacryl gloss tinted to Resene Half Alabaster.



Other ideas:

Try a hot pink combination of Resene Knock Out and Resene Smitten.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm

www.resene.com.au/ artists/artists_canvas.htm.



