Resene

Blackboard clock



Difficulty level ★easy ★★moderate ★★★challenging

Weekend DIY with Mark Rayner - 30

You will need:

- Chalk
- Clean cloth
- Lid from a Resene testpot
- Low-tack masking tape
- Paintbrushes
- Pencil
- Resene Blackboard Paint
- Resene Lustacryl tinted to Resene California
- Resene Quick Dry
- Ruler
- Sandpaper
- Wall clock



Step one

Lightly sand the face of the clock to 'key' the surface. Wipe off any sanding dust with a clean cloth.



Step two

Apply one coat of Resene Quick Dry to the face of the clock and allow to dry for two hours.



Step three

Apply two coats of Resene California to the face of the clock, allowing two hours for each coat to dry.



Step four

Use the testpot lid to draw a circle at each of the '12', '3', '6', and '9' o'clock positions on the face of the clock.



Step five

Mask off wedge-shaped sections, as shown, to represent the remaining numbers around the clock face.



Step six

Paint the circles and masked off sections with two coats of Resene Blackboard Paint, as shown.



Step seven

Before the second coat is fully dry, remove the masking tape. Allow paint to dry.



Step eight

Write in the numbers around the clock face with white chalk, as shown.

It's easy to turn a humble wall clock into a bright and funky feature with a little bit of help from Resene.



To get the look:

Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Barely There.



Other ideas:

Use a combination of Resene Turbo with Resene Blackboard Paint (green, pink and blue) to create a brightly coloured clock for a child's playroom.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm

www.resene.com.au/ artists/artists_canvas.htm.

